

Methodology for applying KABU SHED

SURFACE PREPERATIONS

To ensure the long-term structural integrity of your surface and prevent any future leakage issues, it is critical that the terrace surface is prepared with the correct slope and material specifications before the final waterproofing treatment and any vertical surface shall be prepared with crack filling and free from all dust particles.

Below are the detailed methodology and process.

Application Areas: At bathroom / toilets / kitchen sinks /flower beds / terrace areas / podium / etc.

No. of Coats advised: Base Coat application = min 2 coats, max 3 coats
Top Coat application = 3 coats

Mixing Ratio advised: 1st Coat: 1 : 1
(KABU SHED : CEMENT / KABU TAP Type 2)
2nd Coat: 1 : 1
(KABU SHED : CEMENT / KABU TAP Type 2)
3rd Coat: 1 : 1
(KABU SHED : CEMENT / KABU TAP Type 2)

Note:

For better result you can update the above ratios upto 1: 1.5 as per requirement.

Drying time between coats: Interval of minimum 2 hours between each coat

Full Drying time: 48 Hours for full curing after full application.

For any further information / queries kindly feel free to call our customer care on
080 6218 0982 or email on info@kabu.world