

Methodology for applying KABU BOND

Surface Preparation:

To ensure the long-term structural integrity of your surface and prevent any future leakage issues, it is critical that the terrace surface is prepared with the correct slope and material specifications before the final waterproofing treatment and any vertical surface shall be prepared with crack filling and free from all dust particles.

Below are the detailed methodology and process.

Application Areas:	At bathroom / toilets / kitchen sinks /flower beds / terrace areas / podium / etc.
No. of Coats advised:	Base Coat application = min 2 coats, max 3 coats Top Coat application = 3 coats
Mixing Ratio advised:	1 st Coat: 1 : 1 : 1 (KABU BOND : WATER : CEMENT / KABU TAP Type 2) 2 nd Coat: 1 : 1 : 2 (KABU BOND : WATER : CEMENT / KABU TAP Type 2) 3 rd Coat: 1 : 1 : 2 (KABU BOND : WATER : CEMENT / KABU TAP Type 2)
Drying time between coats:	Interval of minimum 2 hours between each coat
Full Drying time:	48 Hours for full curing after full application.

For any further information / queries kindly feel free to call our customer care on 080 6218 0982 or email on info@kabu.world